

### 41.4.1 State machine conventions

The notational conventions used in the specification of VDP are as stated in Annex E.

### 41.4.2 Bridge VDP state machine

The Bridge VDP state machine shall implement the function defined in Figure 41-7 and the attendant definitions in 41.4.4 through 41.4.7.





Figure 41-7—Bridge VDP state machine

### 41.4.3 Station VDP state machine

The station VDP state machine shall implement the function defined in Figure 41-8 and the attendant definitions in 41.4.4 through 41.4.7.



NOTE - The ".Except" notation used in some exit conditions is described in 41.4.6.

Figure 41-8—Station VDP state machine